Care Instructions



Nortica



PLAY 'n' LEARN Developing Creative Minds

How How to care for your Nortica product

Nortica composite timber is a sustainably sourced and manufactured mixture of ground wood waste and recycled plastic (including recycled plastic milk bottles).

Our Nortica composite timber is manufactured to the highest-achievable level' of slip resistance P5 (AS 4586:2013), making it ideal for children's outdoor furniture and play equipment.

You will never have to sand, stain or oil your outdoor play products ever again! With a Nortica product from Play'n'Learn, simply wash down and occasionally sweep to maintain a beautiful product.

Nortica composite wood carries a 25-year manufactures guarantee.

Nortica Range - Care Instructions

Care & Longevity

Nortica Composite Timber is relatively maintenance free, however, regular cleaning is important in keeping the product looking beautiful.

Sweeping and cleaning with normal household cleaners is usually adequate to keep your Nortica product looking great. "Sugar soap", mixed with water works particularly well.

For stubborn (usually oil-based) stains use a water-diluted degreaser works well – scrub in and wash off after a few minutes. Periodic cleaning of expansion joints is also recommended.

Tests have shown that it is possible to remove graffiti paint by using paint stripper. Use strong chemicals with caution.

General Care for all Outdoor Furniture

All outdoor materials have a limited life span dependent on their environment, you will be required to personally assess your furniture/products.



Developing Creative Minds playnlearn.co.nz



16-20 Wall Place, Linden, Porirua

0508 111 444

sales@playnlearn.co.nz

playnlearn.co.nz





PLAY 'n' LEARN Developing Creative Minds

